

## Vanguard Applications Ware Installing Patches Advisory Notice

---

### Introduction

This notice contains information on how to upgrade the bootprom and install patches which include Service Pak 6.2.S100 and based on Vanguard Applications Ware Release 6.2.R000.

### Bootprom and Custom Images

Bootprom and Custom images can be downloaded using Vanguide.

### Upgrade Bootprom Using Vanguide and Install the Patch Executable File

Follow these steps to upgrade the Vanguard V340 and V342 bootprom using Vanguide, and install the patch executable file:

#### Vanguide Instructions

<b>Step</b>	<b>Action</b>									
<b>1</b>	If you have not already done so, install Vanguard Software Builder from any Vanguide Release 6.2.R000 CD-ROM (Part Number 72608-31 A).									
<b>2</b>	Download the V62T1**.ZIP file (where ** represents a number or letter, for example: 1A) from Vanguard Managed Solutions, please save the file to a local drive on your computer.									
<b>3</b>	Use WinZip® to extract the ZIP file. The V62T1**.ZIP file contains the V62T1**.EXE, bootprom_v340_cldr.xrc, bootprom_2lan_v340_cldr.xrc file, and a copy of this advisory notice in PDF format.									
<b>4</b>	Use the Vanguard Terminal via COM port to download the *.xrc file for a selected platform bootprom upgrade: <table><thead><tr><th><b>Platform</b></th><th><b>Bootprom Version</b></th><th><b>Filename</b></th></tr></thead><tbody><tr><td>V340</td><td>1.1.1</td><td>bootprom_v340_cldr.xrc</td></tr><tr><td>V342</td><td>2.1.1</td><td>bootprom_2lan_v340_cldr.xrc</td></tr></tbody></table>	<b>Platform</b>	<b>Bootprom Version</b>	<b>Filename</b>	V340	1.1.1	bootprom_v340_cldr.xrc	V342	2.1.1	bootprom_2lan_v340_cldr.xrc
<b>Platform</b>	<b>Bootprom Version</b>	<b>Filename</b>								
V340	1.1.1	bootprom_v340_cldr.xrc								
V342	2.1.1	bootprom_2lan_v340_cldr.xrc								



T0263-02 A

### Vanguide Instructions

<b>Step</b>	<b>Action</b>
<b>5</b>	Run or open the V62T1** .EXE executable file from your local drive.
<b>6</b>	The patch executable file prompts you with installation instructions. Insert the Vanguide 6.2.R000 CD-ROM into the CD-ROM drive and select its drive letter. Follow the installation instructions provided by the installer.

#### ■Note

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).

---

### Build an Image

After you install the patch executable file, you must build and load a custom patch image. This table provides general instructions for these procedures:

<b>Step</b>	<b>Action</b>
<b>1</b>	Using Vanguard Software Builder, build a custom patch image by selecting the appropriate patch (V6.2.T1** for example) from the <b>Release</b> drop-down menu. Select features or options that you want to include in the image.
<b>2</b>	Load the custom image using the Vanguard Software Loader.

#### ■Note

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).

---