

## Vanguard Applications Ware Patch 6.2.T16A and Patches Including 6.2.T16A Advisory Notice

---

### Introduction

This notice contains information on how to upgrade the Vanguard 340 and 342 bootproms, coldloaders, and install patch 6.2.T16A which includes Service Pak 6.2.S100 and is based on Vanguard Applications Ware Release 6.2.R000. This Software Release Notice also applies to any patches that include 6.2.T16A.

### Bootprom and Custom Images

Bootprom and Custom images can be downloaded using Vanguide.

### Upgrade Bootprom Using Vanguide and Install the Patch Executable File

Follow these steps to upgrade the Vanguard V340 and V342 bootprom using Vanguide, and install the patch executable file:

#### Vanguide Instructions

<b>Step</b>	<b>Action</b>
<b>1</b>	If you have not already done so, install Vanguard Software Builder from any Vanguide Release 6.2.R000 CD-ROM (Part Number 72608-31 A).
<b>2</b>	Download the V62T1**.ZIP file (where ** represents a number or letter, for example: 1A) from Vanguard Managed Solutions, please save the file to a local drive on your computer.



T0266 A

### Vanguide Instructions

<b>Step</b>	<b>Action</b>									
<b>3</b>	Use WinZip® to extract the ZIP file. The V62T1**.ZIP file contains the V62T1**.EXE, V340\COLDLOAD\C34BP120.xrc V340\COLDLOAD\C42BP230.xrc V340\COLDLOAD\c34v115.xrc V340\COLDLOAD\c34v192.xrc V340\COLDLOAD\c34v2304.xrc V340\COLDLOAD\c34v288.xrc V340\COLDLOAD\c34v384.xrc V340\COLDLOAD\c34v4608.xrc V340\COLDLOAD\c34v576.xrc V340\COLDLOAD\c34v96.xrc files, and a copy of this advisory notice in PDF format.									
<b>4</b>	Mandatory: Use the Vanguard Terminal via COM port to download the *.xrc file for a selected platform bootprom upgrade: <table border="1" data-bbox="568 987 1234 1092"> <thead> <tr> <th><b>Platform</b></th> <th><b>Bootprom Version</b></th> <th><b>Filename</b></th> </tr> </thead> <tbody> <tr> <td>V340</td> <td>1.20</td> <td>C34BP120.xrc</td> </tr> <tr> <td>V342</td> <td>2.30</td> <td>C42BP230.xrc</td> </tr> </tbody> </table>	<b>Platform</b>	<b>Bootprom Version</b>	<b>Filename</b>	V340	1.20	C34BP120.xrc	V342	2.30	C42BP230.xrc
<b>Platform</b>	<b>Bootprom Version</b>	<b>Filename</b>								
V340	1.20	C34BP120.xrc								
V342	2.30	C42BP230.xrc								
<b>5</b>	Run or open the V62T1**.EXE executable file from your local drive.									
<b>6</b>	The patch executable file prompts you with installation instructions. Insert the Vanguide 6.2.R000 CD-ROM into the CD-ROM drive and select its drive letter. Follow the installation instructions provided by the installer.									

### Vanguide Instructions

<b>Step</b>	<b>Action</b>
7	<p>Mandatory: Update the coldloaders before downloading any software images. Copy them as follows:</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v115.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v115.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v192.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v192.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v2304.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v2304.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v288.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v288.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v384.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v384.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v4608.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v4608.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v576.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v576.xrc</p> <p>From C:\V62T1**\V340\COLDLOAD\c34v96.xrc            To C:\VANGUARD\SFW_IMGS\V340\COLDLOAD\c34v96.xrc</p>

■ **Note**

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).

### Build an Image

After you install the patch executable file, you must build and load a custom patch image. This table provides general instructions for these procedures:

<b>Step</b>	<b>Action</b>
1	Using Vanguard Software Builder, build a custom patch image by selecting the appropriate patch (V6.2.T1** for example) from the <b>Release</b> drop-down menu. Select features or options that you want to include in the image.
2	Load the custom image using the Vanguard Software Loader.

■ **Note**

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).